

ONECONTROL® TOUCH PANEL (REV Q/SCREEN REV V2.5) OWNER'S MANUAL

LIPPERT COMPONENTS

TABLE OF CONTENTS

Introduction	2
Operation	2
Power On/Off	•
Control Panel	2
System Operations	3
OneControl Resources	10

Introduction

The OneControl® Touch Panel (OCTP) is a touchscreen device that provides system controls and monitoring software for the recreational vehicle unit. The systems include slide-outs, leveling systems, awnings, lighting, temperature, water tanks, tire pressure, battery levels and any other compatible systems installed on the unit and programmed into the OneControl® system. Powering up the unit will also power the OneControl® Touch Panel and the various controllers throughout the unit.

For information on the assembly or individual components of this product, please visit: https://support.lci1.com/electronics.

NOTE: Images used in this document are for reference only when assembling, installing and/or operating this product. Actual appearance of provided and/or purchased parts and assemblies may differ.

Operation

Power On/Off

1. The device can be powered on or off using the button on the front of the device.


NOTE: It will take a few moments to start up and load the system.

2. To enter or exit sleep mode, press and release the power button.

Control Panel

- 1. Locate OneControl® control panel (Fig. 1).
- 2. Press the power button (Fig. 1A) to turn on the OneControl® Touch Panel.
- **3.** Press the icon of the system to be operated; i.e., awning, bed lifts, generator, etc. (Fig. 2).

NOTE: The control panel will show icons representing the devices connected to the OneControl® system. Press the back button (Fig. 3A) at any time to return to the OneControl® home screen.







System Operations

Press back button (Fig. 3A) in the top-left corner to return to the home screen at any time.


- **1.** Awning, if equipped:
 - **A.** Pressing the Awning icon (Fig. 2) will allow you to access the awning control screen (Fig. 3).
 - **B.** Select an awning to operate.
 - **I.** To extend the awning, press the EXTEND button (Fig. 3B).
 - **II.** To retract the awning, press the RETRACT button (Fig. 3C).



- **2.** Bed Lifts, if equipped:
 - **A.** Pressing the Bed Lifts icon (Fig. 2) will allow you to access the bed lift control screen (Fig. 4).
 - **B.** Select a Bed Lift to operate.
 - **I.** To raise the bed lift, press the RAISE button (Fig. 4A).
 - **II.** To lower the bed lift, press the LOWER button (Fig. 4B).




- **3.** Doors, if equipped:
 - **A.** Pressing the Doors icon (Fig. 2) will allow you to access the door lock control screen (Fig. 5).
 - **B.** Select a door to operate.
 - **I.** To lock the door, press the LOCK button (Fig. 5A).
 - **II.** To unlock the door, press the UNLOCK button (Fig. 5B).




4. Fan, if equipped:


- **A.** Pressing the Fan icon (Fig. 2) will allow you to access the fan control screen (Fig. 6).
- **B.** Press a fan to turn it ON (Fig. 6A) or OFF (Fig. 6B).




- **5.** Generator, if equipped:
 - **A.** Pressing the Generator icon (Fig. 2) will allow you to access the generator control screen (Fig. 7).
 - **B.** Select a generator to operate.
 - **I.** To start the generator, press the START button (Fig. 7A).
 - **II.** To access the auto-start menu and set maintenance intervals, choose auto-start voltage, etc., press the SETTINGS button (Fig. 7B) on the left side of the screen.




- **6.** HVAC, if equipped:
 - **A.** Pressing the HVAC icon (Fig. 2) will allow you to access the HVAC control screen (Fig. 8).
 - **B.** Select an HVAC zone to control (Fig. 8A).
 - **C.** Selecting a zone will bring you to the climate zone control screen.
 - **I.** Toggle the heating or cooling on or off by pressing the HVAC control button (Fig. 9A).
 - II. Adjust the fan strength by pressing the HVAC fan control button (Fig. 9B).



- **7.** Landing Gear, if equipped:
 - **A.** Pressing the Landing Gear icon (Fig. 2) to access the landing gear control screen (Fig. 10).
 - **I.** To extend the landing gear, press the EXTEND button (Fig. 10A).
 - **II.** To retract the landing gear, press the RETRACT button (Fig. 10B).




- **8.** Levelers, if equipped:
 - **A.** Pressing the Levelers icon (Fig. 2) will allow you to access the leveling user interface (Fig. 11).
 - **I.** To level the unit, press the AUTO LEVEL button (Fig. 11A).




- **9.** Lighting, if equipped:
 - **A.** Pressing the Lighting icon (Fig. 2) will allow you to access the lighting control screen (Fig. 12).
 - I. Pressing the highlighted ALL ON or ALL OFF (Fig. 12A) will turn all lights on or off.
 - **II.** Pressing the highlighted ON or OFF (Fig. 12B) will turn individual lights on or off.
 - **III.** If the unit is equipped with colored lighting, pressing the settings icon (ellipsis) (Fig. 12C) will allow the adjustment of the light name, mode, color, intensity and speed (Fig. 13).


NOTE: Status of individual lights is displayed by the light bulb to the left of the light name. The light icon will display a lit bulb (Fig. 12D) if the light is on and a dim bulb (Fig. 12E) if the light is off.




- **10.** Tank Monitor, if equipped:
 - **A.** Pressing the Monitor Panel icon (Fig. 2) will allow you to access the tank monitor control screen (Fig. 14).
 - **B.** The monitor tank capacity levels (Fig. 14A) to the left will show current fill levels for a given tank.
 - **C.** Pressing the device buttons on the right (Fig. 14B) will activate the component. The icon to the right will turn green when the corresponding device is in use (Fig. 14C).




- **11.** Slides, if equipped:
 - **A.** Pressing the Slides icon (Fig. 2) will allow you to access the slide-out control screen (Fig. 15).
 - **B.** Select a slide-out to operate.
 - **I.** Pressing OUT will extend the slide-out (Fig. 15A).
 - **II.** Pressing IN will retract the slide-out (Fig. 15B).



- **12.** Stabilizers, if equipped:
 - **A.** Pressing the Rear Stabilizer icon (Fig. 2) will allow you to access the rear stabilizer control screen (Fig. 16).
 - **B.** Select a stabilizer to operate.
 - **I.** To extend the rear stabilizer, press the EXTEND button (Fig. 16A).
 - **II.** To retract the rear stabilizer, press the RETRACT button (Fig. 16B).




- **13.** TV Lifts, if equipped:
 - **A.** Pressing the TV Lift icon (Fig. 2) will allow you to access the TV lift control screen (Fig. 17).
 - **B.** Select a TV lift to operate.
 - **I.** To raise the TV lift, press the RAISE button (Fig. 17A).
 - **II.** To lower the TV lift, press the LOWER button (Fig. 17B).



14. Vent Covers, if equipped:

- **A.** Pressing the Vent Covers icon (Fig. 2) will allow you to access the vent cover control screen (Fig. 18).
- **B.** Select a vent cover to operate.
 - **I.** To open the vent cover, press the OPEN button (Fig. 18A).
 - **II.** To close the vent cover, press the CLOSE button (Fig. 18B).




OneControl Resources

Pressing the MyRV icon (Fig. 2) will allow you to access the MyRV OneControl resources.

NOTE: The following documents and resources on the OneControl® Touch Panel are pre-loaded on the system at the time of manufacture. For the latest revisions, visit www.lci1.com.

There are various operation and information videos (Fig. 19A) including troubleshooting and maintenance guides (Figs. 19B and 20).

NOTE: Troubleshooting videos may not be specific to any unit.



NOTE: Figure 19 image is modified to show full menu options.



1. Owner's Manuals (Fig. 21); product documentation containing operation and basic troubleshooting (Fig. 22).

NOTE: Product documentation may not be specific to any unit.






2. Search Function (Fig. 23); searches the OneControl® tablet for any files (documentation, videos, images, etc.) containing the search term.

NOTE: Enter search terms into search pop-up and press the search button (Fig. 23A) to view all related files.

3. FAQs (Fig. 24); frequently asked questions with drop down answers.

NOTE: Press the question to reveal the answer and a link to more information.





- **4.** Apps (Fig. 25); manage the tablet and information settings.
 - **A.** OneControl® Media Sync (Fig. 25A) allows the manufacturer to manage documentation supplied on OneControl®.
 - **B.** Set Date & Time (Fig. 25B) manages the clock and calendar settings.





COMPONENTS

The contents of this manual are proprietary and copyright protected by Lippert Components, Inc. ("LCI"). LCI prohibits the copying or dissemination of portions of this manual unless prior written consent from an authorized LCI representative has been provided. Any unauthorized use shall void any applicable warranty. The information contained in this manual is subject to change without notice and at the sole discretion of LCI. Revised editions are available for free download from lci1.com.

Please recycle all obsolete materials.

For all concerns or questions, please contact Lippert Components, Inc.

Ph: (574) 537-8900 | Web: lci1.com | Email: customerservice@lci1.com